

尺寸: 90x90mm



Specification

Model Name: UB2609 Cell Type: Lithium Ion Battery Capacity: 2600mAh/ 9.62Wh Single earbud capacity: 50mAh Rated Input: 5V/ 0.5A (Max.) Rated Output: 5V/1A (Max.) Bluetooth Version: 5.0 Impedance : $\Phi 6mm~32\Omega$ Transmission distance:10M Frequency Range: 20Hz~20KHz Protocols: HSP/ HFP/ A2DP/ AVRCP Dimensions: 82(L) x 53(W) x 36(H) mm Weight: 98g±5g





How to Use

Power on: Take the earbuds out of the case, the power will turn on automatically. You can also touch and hold MFB button for 2 seconds to turn on the power manually. Power off: Put the earbuds back into the case, the power will turn off automatically. You can also touch and hold MFB for 4 seconds, the red light on the indicator will shut off, *If the 2 earbuds are connected, press one of the earbuds, the 2 earbuds will turn off

LED Light Indicator:

Earbuds LED Light Indicator

Pairing Mode:	Flashing blue and red light
Earbuds Connected:	One flashes blue and red, the other one flashes blue 1 time every 5 seconds
Phone Connected:	Both earbuds flash blue 1 time every 5 seconds
Battery Low:	Flashing red
Charging:	Red light on
Charging finished:	Blue light on for 1 min then shut off



- 1. Left Earbud Battery Level
- 2. Charging Case Battery Level
- 3. Right Earbud Battery Level


Pairing Instruction:

Take the 2 earbuds out of the box, they will automatically pair first, one earbud flashes blue, the other one flashes blue and red indicate pairing is completed.

Turn on the Bluetooth of your phone, connect to "Energizer_UB2609". Open your phone music player app and play, you can enjoy music wirelessly


Auto-connect:

Turn on the Bluetooth on your phone first, and then turn on the earbuds. It will automatically connect the last paired phone device when turned on next



Button Operation:


Touch and hold MFB for 2 seconds:





Touch 2 times: Redial
Touch 3 times: Activate phone voice control
Touch and hold for 4 seconds: Power off

Connect the charging cable to the box, and connect to a power outlet to recharge



RF Exposure Compliance Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

CORRECT DISPOSAL OF THIS PRODUCT

(Waste Electrical & Electronic Equipment)

Charging cable

This making shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from

uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household user should contact either the retailer where they purchased this product or their local government office for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Safety Instruction

- Avoid water, heat, fire, penetration of the battery, and severe drops at all times.
- Do not insert other objects into the USB ports other than the USB connectors.
- Once the product is fully charged, your power pack automatically shuts off to save power
- During charge & recharge, battery may feel slightly warm.
- Do not clean the battery with water or other cleaning products, clean the exterior with a lightly wetted cloth or napkin
- Any intentional and physical damage to the battery will not be under the warranty conditions
- Battery storage temperature is between -10°C~+60°C, operating temperature is 0°C~45°C
- Fully charge the battery before first use to maximize the battery life
- Recommend to recharge your power bank with a wall charger/adapter. • For better performance, avoid recharging the power bank while your device is connected to it.
- Dispose of battery properly; ask local disposal facility for advice.
- Do not disassemble, damage or incinerate the battery at any time.
- Please use the original accessories such as charging cable and adapter for better performance

Samsung's voice assistant Bixby may cause compatibility issues.

If there's no response from the touch-control button, please register Bixby and log in, then you can use the full functions with UB2609.

WARRANTY



PowerSafe Management

Guarantees against short circuit and over-charging for your power bank and devices.



For any question about the product, please contact





UM_2_UB2609_ML_1.3