

## MULTIFUNCTION CABLE FAULT TESTER

### NF-868A



#### Accessories Included:

Earphone x 1 set  
Battery x 2 sets  
Telephone line adapter x 1 set  
Network cable adapter x 1 set  
Cable clips x 1 set

#### Attention:

1. Don't connect high voltage lines to avoid burning out the machine.
2. Don't connect telephone cable into RJ45 Port.
3. Put into the right place to avoid hurting others, because of the sharp part.
4. Read the user manual before use it.



#### Applications Include:

- Check cables errors for RJ45, RJ11, BNC, USB Cable (open, short, cross, crosstalk).
- Measure cable length for RJ45, RJ11, BNC, USB Cable accurately.
  - Remote unit with tones when checking cable wiremap.
  - Memory and storage function.

#### Benefits:

- LCD Screen shows test result clearly.
- Low voltage alarm function.

#### Technical indexes

NF-868A Transmitter specifications	
LCD screen	53x25mm
The Max. distance of cablemapping	2500m
The Max. distance of cable length testing	1000m
Trace cable connected to switch	Anti-jamming
Tone mode	2 Tones, adjustable
Compatible with connectors	RJ11, RJ45, BNC, USB
LED lights display	Wiremap, tone, tracing
Cable map indication	LCD (Pin#1- Pin#8)
Shielded indication	LCD (G for shielded)
Voltage protection	AC 60V/DC 42V
Low battery display	LCD (6.5V)
Battery type	DC 9.0V(NEDA 1604/6F22 DC9Vx1pcs)
Dimension (LxWxD)	185x80x32mm
NF-868A Remote unit specifications	
Compatible connectors	RJ11, RJ45, BNC, USB
Dimension (LxWxD)	107x30x24mm

## MULTIFUNCTION CABLE TESTER

### NF-868W



#### Accessories Included:

Earphone x 1 set  
Battery x 2 sets  
Telephone line adapter x 1 set  
Network cable adapter x 1 set  
Cable clips x 1 set

#### Attention:

1. Don't connect high voltage lines to avoid burning out the machine.
2. Don't connect telephone cable into RJ45 Port.
3. Put into the right place to avoid hurting others, because of the sharp part.
4. Read the user manual before use it.



#### Applications Include:

- Test 4 types of cable: RJ11, RJ45, BNC, USB Cable
- Test open, short, cross, reverse, and broken.
- Capable to measure length and determine broken location.
- Find the target wire or cable among plenty of wires.
- Tone trace cable with AC Interference Rejection.
- Two scan modes: ordinary Switch/PoE Switch.

#### Benefits:

Enables cables to be located even when totally concealed.

Memory and storage function.

8 remote units improve work efficiency.

LCD Screen shows test result clearly.

#### Technical indexes

NF-868W Transmitter specifications	
LCD screen	53x25mm
Tone frequency	130KHz
The Max. distance of tracing cable	3000m
The Max. distance of cablemapping	2500m
The Max. distance of cable length testing	1000m
Trace cable connected to switch	Anti-jamming
Tone mode	2 Tones, adjustable
Compatible with connectors	RJ11, RJ45, BNC, USB
LED lights display	Wiremap, tone, tracing
Cable map indication	LCD (Pin#1- Pin#8)
Shielded indication	LCD (G for shielded)
Voltage protection	AC 60V/DC 42V
Low battery display	LCD (6.5V)
Battery type	DC 9.0V(NEDA 1604/6F22 DC9Vx1pcs)
Dimension (LxWxD)	185x80x32mm
NF-868W Receiver specifications	
Frequency	130KHz
the Max. working current	Less than 70mA
Ear jack	1
LED illumination	2 LEDs
Battery type	DC 9.0V(NEDA 1604/6F22 DC9Vx1pcs)
Dimension(LxWxD)	218x46x29mm
NF-868W Remote unit specifications	
Remote identifier	8 pcs
Compatible connectors	RJ11, RJ45, BNC, USB
Dimension (LxWxD)	107x30x24mm